

Underhåll/skötsel av produkter med batterier. Maintenance/handling of products with batteries.



Om strömtillförseln till armaturen bryts i mer än 24 timmar måste batteriet kopplas ur.

En de-centraliserad nödljusprodukt skall alltid matas via en fast laddfas!

Batterierna innehåller material som måste återvinnas eller kasseras på rätt sätt
Får inte kasseras som osorterat avfall Följ ALLTID gällande lokala rekommendationerna
och/eller regler som styr miljöskydd och de risker som förknippas med återvinning eller
kassering av utrustningen när den inte längre kan användas Dekontaminera ALLTID
ett batteripaket som exponerats för infektiöst material innan det sänds till en
avfallsanläggning



If the power supply to the luminaire is interrupted for more than 24 hours, the battery must be disconnected.

A decentralized emergency lighting product must always be fed via a fixed charging phase!

The batteries contain materials that must be recycled or disposed of properly
Must not be disposed of as unsorted waste ALWAYS follow the applicable local recommendations
and/or rules governing environmental protection and the risks associated with recycling or
disposal of the equipment when it can no longer be used ALWAYS decontaminate
a battery pack exposed to infectious material before being shipped to a
waste facility