

ECU-2Te

Digital uketimer - Digital ugetimer - Digitaalinen viikkoajastin - Digitalt veckour
 Digital weekly timer - Horloge hebdomadaire numérique - Digitaler Wochenzeitschaltuhr
 Digitale wekelijkse timer - Dijital haftalık zamanlayıcı - Цифровой недельный таймер
 Ψηφιακός εβδομαδιαίος χρονοδιακόπτης - Digitális heti időzítő
 Digitalni tjedni mjerač vremena - Седмичен програматор

zebra

Rexel Sverige AB, Prästgårdsgränd 4, 125 44 Älvsjö




Electronic room temperature control
 plus week timer with adaptive startup.


**Montering
 Montage
 Asennus**
**Assembly
 Montaj
 Монтаж**
**Συναρμολόγηση
 Összeszerelés
 Montaža**
**Demontering
 Irroitus
 Disassembly
 Démontage**
**Demontage
 Sökme
 Разборка**
**Αποσυναρμολόγηση
 Szétszerelés
 Demontaža**

1

av, pois, off, désactivé
 aus, uit, karalı, выкл,
 απενεργοποιήστε, ki, isklj.



2




3




Klikk
 Klick
 Napsauta
 Click
 Cliquez
 Klicken
 Klik
 Tik
 Защелкнуть
 Κλικ
 Kattanás

1

av, pois, off, désactivé
 aus, uit, karalı, выкл.
 απενεργοποιήστε, ki, isklj.



2



1 Still dag og klokke.
 Indstil dag og tid.
 Aseta päivä ja aika.
 Ställ in dag och tid.
 Set day and time.

Configuration jour et heure.
 Tag und Uhrzeit einstellen.
 Dag en uur-instelling.
 Gün ve saati ayarlayın.
 Установка даты и времени.


Ρυθμίστε ημέρα και ώρα.
 Állítsa be a napot és az időt.
 Namjestite dan i vrijeme.
 Нагласете датата и часа

2 Temperatur
 Lämpötila
 Temperature
 Temperatur

Σıcaklık
 Температура
 Θερμοκρασία
 Hőmérséklet
 Temperatura

Trykk samtidig på + og -
 Tryk samtidigt på + og -
 Paina samanaikaisesti + ja -
 Tryck samtidigt på + och -
 Press + and - simultaneously
 Appuyez simultanément sur + et -
 Gleichzeitig + und - drücken

Druk tegelijkertijd op + en -
 Αγνι anda + ve -
 Нажмите одновременно + и -
 Πατήστε ταυτόχρονα + και -
 Nyomja meg egyszerre a + és - gombot
 Pritisnite istovremeno + i -
 Натиснете + и - едновременно



A: Still inn time
 Indstil time
 Aseta tunti
 Ställ in timme
 Set the hour

Régler l'heure
 Stunde einstellen
 Stel het uur in
 Saati ayarla

Установите час
 Ρυθμίστε τις ώρες
 Állítsa be az órát
 Namjestite sat
 Нагласете часа



B: Bekreft
 Bekræft
 Vahvista
 Bekräfta
 Confirm

Confirmer
 Bestätigen
 Bevestigen
 Onayla


Подтвердите
 Επιβεβαιώστε
 Jónáhagyas
 Potvrditi
 Потвърдете



C: Still inn minutt
 Indstil minut
 Aseta minuutti
 Ställ in minut
 Set the minutes

Régler les minutes
 Minuten einstellen
 Stel de minuut in
 Dakikayı ayarla

Установите минуты
 Ρυθμίστε τα λεπτά
 Állítsa be a percet
 Namjestite minute
 Нагласете минутите



D: Bekreft
 Bekræft
 Vahvista
 Bekräfta
 Confirm

Confirmer
 Bestätigen
 Bevestigen
 Onayla


Подтвердите
 Επιβεβαιώστε
 Jónáhagyas
 Potvrditi
 Потвърдете



E: Still inn dag
 Indstil dag
 Aseta päivä
 Ställ in dag
 Set the day

Régler le jour
 Tag einstellen
 Stel de dag in
 Günü ayarla

Установите день
 Ρυθμίστε την ημέρα
 Állítsa be a napot
 Namjestite dan
 Нагласете дня




F: Bekreft
 Bekræft
 Vahvista
 Bekräfta
 Confirm

Confirmer
 Bestätigen
 Bevestigen
 Onayla


Подтвердите
 Επιβεβαιώστε
 Jónáhagyas
 Potvrditi
 Потвърдете




M	T	W	T	F	S	S
Mandag	Tirsdag	Onsdag	Torsdag	Fredag	Lørdag	Søndag
Maanantai	Tiistai	Keskiviikko	Torstai	Perjantai	Lauantai	Sunnuntai
Måndag	Tisdag	Onsdag	Torsdag	Fredag	Lördag	Söndag
Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday
Lundi	Mardi	Mercredi	Jeudi	Vendredi	Samedi	Dimanche
Montag	Mittwoch	Donnerstag	Freitag	Samstag	Sonntag	Sonntag
Maandag	Dinsdag	Woensdag	Donderdag	Vrijdag	Zaterdag	Zondag
Pazartesi	Salı	Çarşamba	Perşembe	Cuma	Cumartesi	Pazar
Понедельник	Вторник	Среда	Четверг	Пятница	Суббота	Воскресенье
Δευτέρα	Τρίτη	Τετάρτη	Πέμπτη	Παρασκευή	Σάββατο	Κυριακή
Hétfő	Kedd	Szerda	Csütörtök	Péntek	Szombat	Vasárnap
Ponedjeljak	Utorak	Srijeda	Četvrtak	Petak	Subota	Nedjelja
Понеделник	Вторник	Сряда	Четвъртък	Петък	Събота	Неделя



Komfort - Mukavuus - Comfort - Confort - Konfor
 Комфорт - Άνεση - Komfort - Udobnost



Øko - Eco - Säastö - Öko - Эко - Οικον - Eko
 Takarék - Ušteda



(N) Ovnen må ikke tildekkes.
 (DK) Ovnen må ikke tildækkes.
 (FI) Lämmitintä ei saa peittää.
 (SE) Elementet får inte övertäckas.
 (EN) Do not cover the heater.
 (FR) Ne pas couvrir l'appareil
 (DE) Heizung nicht abdecken.
 (NL) Het toestel niet afdekken
 (TR) Üstünü Kapatmayınız
 (RU) Не накрывайте обогреватель.
 (GR) Μην καλύπτετε τη συσκευή θέρμανσης.
 (HU) Ne takarja le a fűtőpanelt.
 (BiH, HR, MNE) Ne prekrivajte radiator.
 (BG) Не покривайте уреда